

EXHIBIT A

Existing metal cap to be eliminated on the internal parapet wall, as illustrated by the yellow arrows below. No metal to be installed on this internal parapet wall beyond front stop at EFIS transition.

Canted wood blocking under this existing metal cap to be removed and replaced with new, non-canted wood blocking, attached to the top of the internal parapet wall with fasteners appropriate to the material being used.

EDPM roofing to be installed over new wood cap and both sides of interior parapet wall.

